


Glidermatic GTS+

Setting Door Travel Limits

The following instructions demonstrate how to set the travel limits of your Gliderol Sectional door. Setting your door travel limits is a vital part of the initial setup of your Glidermatic GTS+ operator. This communicates to the operator the specific distance it must travel to complete an open/close cycle. All steps must be completed in quick succession to prevent the unit from exiting Limit setup mode.


Step 1:



Press and hold the 'Enter' button (shown above) for 2 seconds to access the operator menu. The unit will beep twice to confirm this has been selected.


Note: Pressing the enter button for 5 seconds or more will erase all handset data from your operator - be careful not to press the enter key for longer than necessary.

Step 2:



Use the arrow (Up & Down) buttons to select the 'Limit' option and press 'Enter' to confirm selection.

Step 3:



Set the top/open door limit by using the arrow (Up & Down) buttons on the operator (or the buttons on your Gliderol Handset) to raise the door to its open position. Press 'Enter' to confirm limit. Set the bottom/close door limit by using the arrow buttons or your Gliderol handset to lower the door to its closed position. Press 'Enter' to confirm limit.

Your handset programming is now complete!



Once limits are set the unit will automatically perform a full calibration cycle. When the door is closed after calibration, the limits are successfully setup and your door ready to use.